MONTECH


LUMI HUB Update Firmware SOP

English	P.2
繁體中文	P.6


LUMI HUB

English


Step 1: Open MONTECH LUMI HUB Firmware Update tool



Step 2: Get Ready for LUMI HUB




Connect the LUMI HUB to the motherboard using the USB Type-C to Internal USB 2.0 cable.



Connect the 6Pin PCIe power cable from the LUMI HUB to PSU PCIe cable.

Step 3: MONTECH LUMI HUB Firmware Update tool




1.
Make sure the Connect Status shows “Connected”.

2.
Click “Upgrade” and wait for the process to complete.
A “Success” message will appear.


LUMI HUB

繁體中文


第一步：開啟MONTECH LUMI HUB Firmware Update tool



第二步：準備好LUMI HUB




使用USB Type-C轉內部USB 2.0線材，將LUMI HUB連接至主機板。



將6Pin PCIe電源線從LUMI HUB連接至電源供應器PCIe線材。

第三步：準備好MONTECH LUMI HUB Firmware Update tool



1.
確認連線狀態顯示為「Connected」。

2.
點擊「Upgrade」並等待進度完成。
完成後會顯示「Success」。